

Continue

10963975.103896 81159239.24 15070940055 5906444.3970588 22560793 103963785422 115936092.11765 9223408320 10030182024 18173519.678161 4102101163 113415501562 616230.6984127 51051723795 5488376.22 65407255242 13090627.066667 1458174259 577435238 2952260.6179775 24930408963 60673298.411765 2012857.2222222 18341042.670213

Keurig owners manual b40 instructions manual instructions

SECTION 1 Set-Up & First Brew

IMPORTANT: You cannot use your Keurig Brewer until it has been set-up for its first use as set forth below.

NOTE: If Brewer has been exposed to temperatures below freezing, allow Brewer at least two hours to reach room temperature before brewing. A frozen or extremely cold brewer will not operate.

fig. 1

Setting Up Your Brewer

1. Unwrap cord and plug the Brewer into a grounded outlet. Remove all pieces of packing tape.
2. Place a Large Mug (10 oz. minimum) on the Drip Tray Plate.
3. Remove the Water Reservoir from Brewer by first removing Lid from Reservoir (fig. 1), then Lifting Reservoir straight up and away from Brewer (may be tight). Rinse with fresh water.
4. Fill Water Reservoir with bottled or filtered water so that the water level reaches the line just below the top edge of the clear viewing area. (Be careful not to over fill.)

fig. 2

5. Place Water Reservoir base into the left side of the Brewer and be sure the Water Reservoir Lock Tabs engage with the Brewer (fig. 2). Replace Lid on Water Reservoir.
6. Press Power Button found on upper right panel of the Brewer. The green light next to the Power Button will become illuminated.

NOTE: A K-Cup should not be used for this Sequence.

fig. 3

NOTE: If the Water Reservoir is empty or not in place on the Brewer, the blue light next to "ADD WATER" on the LED Control Center will be illuminated. The Small Mug Button will not be activated until water is added to the Water Reservoir.

7. The Brewer will automatically fill with water and then the water will be heated. This will take about 4 minutes. During the heating period the red light next to "HEATING" on the LED Control Center will become illuminated. Once the water is heated, the red light will turn off and the Small Mug Button will flash.

NOTE: Do not Lift Brewer Handle during this "heating period".

KEURIG

Keurig B200 Mid-Size Office Brewer Key Features



cULus Commercial 16 INCHES HIGH x 10.25 INCHES WIDE x 18 INCHES DEEP 24 POUNDS (EMPTY)

Call: 1 - 888 - CUP - BREW (888-287-2739)



ATTENTION : Le godet K-Cup® est perforé par deux aiguilles, une au-dessus du support à K-Cup et l'autre au fond du support à K-Cup. Pour éviter tout risque de blessure, ne pas mettre les doigts dans le compartiment de la K-Cup.

ATTENTION : L'eau se trouvant dans le support à K-Cup durant l'infusion est extrêmement chaude. Pour éviter tout risque de blessure, ne pas soulever la poignée et ouvrir le boîtier du support à K-Cup durant l'infusion.

INSTRUCTIONS POUR CORDON D'ALIMENTATION COURT : L'appareil est muni d'un cordon d'alimentation court pour éviter qu'il s'emmêle ou que quelqu'un trébuche sur un cordon long.

Si une rallonge est utilisée, (1) les caractéristiques électriques inscrites sur la rallonge doivent égaler ou excéder celles de l'appareil, (2) le cordon doit être tiré de façon à ce qu'il ne pende pas d'une table ou d'un comptoir pour éviter qu'un enfant puisse le saisir ou que quelqu'un trébuche et (3) la rallonge doit être munie d'une prise de mise à la terre à trois broches.

CE PRODUIT EST DESTINÉ À UNE UTILISATION DOMESTIQUE SEULEMENT

AVERTISSEMENT CE PRODUIT CONTIENT DES PRODUITS CHIMIQUES RECONNUS PAR L'ÉTAT DE LA CALIFORNIE COMME CAUSE DE CANCER, DES ANOMALIES CONGÉNITALES OU D'AUTRES PROBLÈMES DE REPRODUCTION.

AVERTISSEMENT

RISQUE D'INCENDIE ET DE CHOC ÉLECTRIQUE

NE PAS OUVRIR!

AVERTISSEMENT POUR RÉDUIRE LES RISQUES D'INCENDIE OU DE CHOC ÉLECTRIQUE, NE PAS ENLEVER L'ENVELOPPE. NE CONTIENT AUCUNE PIÈCE RÉPARABLE PAR L'UTILISATEUR. CONFIER LES RÉPARATIONS DE L'APPAREIL À UN CENTRE DE SERVICE AUTORISÉ.

TABLE DES MATIÈRES

SYSTÈME D'INFUSION GOURMET UNE TASSE À LA FOIS DE KEURIG® 2.0 — Modèles B40

RÉGLAGES
Conseils utiles 97
Câblage 97
Caractéristiques 98

SECTION 1 — PRÉPARATION ET PREMIÈRE INFUSION
Préparation et première infusion 99

SECTION 2 — COMMANDES ET VOYANTS
Programmation de la fonction de minuterie (2 or 8) automatique 101

SECTION 3 — NETTOYAGE ET ENTRETIEN
Nettoyage 103
Détartrage 104
Entreposage 104

SECTION 4 — DÉPANNAGE 104

SECTION 5 — GARANTIE 107

Inscrivez le numéro de série de votre cafetière ici.

_____

Le retrait de l'étiquette du numéro de série annulera la garantie.

Keurig b40 manual. Keurig k40 owners manual.

12pour des directives en Français,veuillez voo reporter à la page 13. warningrisk of fire or electric shocked not openwarning: to reduce the risk of firerecord your brewer serial number here. or electric shock, not remove the serial number is located in the bottom cover. the green light of the power will illuminate. documents: Go to donwload! manual of the owner - (English) keurig b40 elitetable SET-UPHelpful hintsunpacking character brewsection 1—SET-UP & first BREWSet-Up > first brewsection 2-CONTROLS " indicators programming auto off timer featuresection 3—CLEANING " MAINTENEC Once the water is warmed, the red heating light will be turned off and the small cup, the small cup and the big cup buttons will be lit. press the small button of the cup to start a cleaning process (fig. .6brew process. section 2short cord instructions: a short powerled control center. pour the hot water into the sink. The brew may take 15 seconds to reheat the water between breweries during which the red heating light can be illuminated. new added: b31 mini plus b30 k130 k920 k910 tags: keurig k express essentials, how to use keurig mini plus, keurig B60, keurig k elite manual, keurig k express, keurigk duo, k express keurig bolt Z600 – owner's manual / user guide manual keurig b30 - owner's manual/ Instructions User Guide Keurig B41 – Owner's Manual / Instructions User Guide Keurig B44 Classic – Owner's Manual / ♪♪♪♪ ♪♪ ♪♪♪♪